

inReach Support Center

Knowledgebase > inReach Devices > inReach SE > How-To > Activating an inReach Device (Existing User)

Activating an inReach Device (Existing User)

Administrator - 2017-03-07 - Comments (0) - How-To

Before you can use your inReach device, you must activate it.

This article explains how to active an inReach for existing users.

1. Login to your account by navigating to <https://inreach.garmin.com/>
2. Select **Account** tab followed by **Plans & Devices**.
3. Select **Add Device** and proceed with the activation prompts.
4. Once you've completed the activation prompts, power on the inReach device.
5. Follow the on-screen instructions.
6. When prompted, go outdoors to an open area with a clear view of the sky.
7. Wait while the device communicates with the Iridium satellite network.
8. Once the activation has been completed, your inReach will be unlocked.

NOTE: It may take up to 20 minutes to activate your device. The device must send and receive several messages, which takes longer than sending a single message during regular use.