

inReach Support Center

Portal > Knowledgebase > Getting Started > Activating an inReach Device (New User)

Activating an inReach Device (New User)

Lu Parente - 2017-07-05 - 0 Comments - in Getting Started

Before you can use your inReach device, you must activate it.

This article explains how to activate an inReach device for new users.

1. Create an account by navigating to <https://inreach.garmin.com/>
2. Below the heading Create an Account, select inReach.
3. Power on the inReach device.
4. Follow the on-screen instructions.
5. When prompted, go outdoors to an open area with a clear view of the sky.
6. Wait while the device communicates with the Iridium satellite network.
7. Once the activation has been completed, your inReach will be unlocked.

NOTE: It may take up to 20 minutes to activate your device. The device must send and receive several messages, which takes longer than sending a single message during regular use.