

inReach Support Center

Portal > Knowledgebase > inReach Devices > inReach Explorer+ > How-To > Calibrating Compass using inReach Explorer+

Calibrating Compass using inReach Explorer+

Administrator - 2018-10-25 - 0 Comments - in How-To

The Compass is a tool used to assist with geographic direction. The compass features and appearance change depending on whether you are tracking or navigating to a destination.

This article explains how to calibrate the compass.

NOTICE: Calibrate the electronic compass outdoors. To improve heading accuracy, do not stand near objects that influence magnetic fields, such as vehicles, buildings, and overhead power lines.

If you experience irregular compass behavior, for example, after moving long distances or after extreme temperature changes, you can manually calibrate the compass.

1. Select **Settings** and press ✓
2. Select **Compass & Altimeter** and press ✓
3. Select **Calibrate Compass** and press ✓
4. Follow the on-screen instructions to complete the calibration process.