

inReach Support Center

Portal > Knowledgebase > inReach Devices > inReach SE > How-To > Change Datum on the Earthmate App for Apple iOS

Change Datum on the Earthmate App for Apple iOS


Administrator - 2015-06-02 - 0 Comments - in How-To

Follow the steps below on how to change Datum on the inReach SE & inReach Explorer.


1. Go to "Settings."




2. Select "Units."



3. Select "Datum."



4. Select a datum option (WGS84 is the recommended default).



More information on datums can be found here:

Basic definition: http://en.wikipedia.org/wiki/Geodetic_datum

Datum basics by

ESRI: http://webhelp.esri.com/arcgisdesktop/9.2/index.cfm?TopicName=Projection_basics_the_GIS_professi

[onal_needs_to_know](#)