

inReach Support Center

Knowledgebase > inReach Devices > inReach SE+ > How-To > Changing Display Settings on inReach SE+ / Explorer+

Changing Display Settings on inReach SE+ / Explorer+

Administrator - 2017-03-10 - Comments (0) - How-To

The Display Settings menu on your inReach allows you personalize the behavior and look of your display.

To change your Display Settings:

1. Select **Settings** and press ✓
2. Select **Display** and press ✓
3. Select an option from the list and press ✓

Auto Screen Lock

Automatically locks the keys when the backlight times out to prevent inadvertent key presses.

Color Scheme

Sets the device to display light or dark colors.

Brightness

Sets the backlight brightness. If you select the **Automatic** option, the device automatically adjusts the backlight brightness based on the ambient light.

Timeout

Sets the length of time before the backlight turns off.

Always On With Ext. Pwr.

Sets the power mode when connected to external power.