

inReach Support Center

Portal > Knowledgebase > inReach Devices > inReach SE+ > How-To > Changing External Power Settings on inReach SE+ / Explorer+

Changing External Power Settings on inReach SE+ / Explorer+

Administrator - 2017-03-10 - 0 Comments - in How-To

The External Power Settings menu on your inReach allows you to manage when your device should automatically power on and off based on when external power is supplied or removed.

To change your External Power Settings:

1. Select **Settings** and press ✓
2. Select **Power Settings** and press ✓
3. Select an option from the list and press ✓

Auto On

Automatically turns on the device when it is connected to external power.

Auto Off

Automatically turns off the device when it is disconnected from external power.