

inReach Support Center

Portal > Knowledgebase > inReach Devices > inReach SE+ > How-To > Changing Tracking Setting on inReach SE+ / Explorer+

Changing Tracking Setting on inReach SE+ / Explorer+

Administrator - 2017-03-10 - 0 Comments - in How-To

The Tracking Settings menu on your inReach allows you configure settings related to how your device sends tracks and logs position details.

To change your Map Settings:

1. Select **Settings** and press ✓
2. Select **Tracking** and press ✓
3. Select an option from the list and press ✓

Send Interval

Sets the frequency at which the device records a track point and transmits it over the satellite network when you are moving. If you are an enterprise customer, you can also specify the send interval for when you are stationary.

Log Interval

Sets the frequency at which the device logs your location and updates the track line on the map.

Extended Tracking

Sets the device to enter sleep mode between track points to maximize battery life. Sleep mode disables Bluetooth wireless technology, detailed track lines, and message checking.

Prompt for MapShare

Sets the device to prompt you to send a message with your MapShare link when you start tracking.

Auto Track

Sets the device to start tracking when you turn on the device. This setting is only available for enterprise customers.

Burst Tracking

When tracking, sets the device to create and send a detailed track line to provide the best approximation of your location. You can select the amount of data to use, and the device will create as many track points as possible. This setting is only available for enterprise customers.