

# inReach Support Center

Portal > Knowledgebase > inReach Devices > inReach Explorer+ > How-To > Deleting Downloaded Maps on inReach Explorer+

---

## Deleting Downloaded Maps on inReach Explorer+

Administrator - 2017-03-10 - 0 Comments - in How-To

You can delete all downloaded maps on your device to free up space and later download the maps that are of interest to you.

This article explains how to delete all downloaded maps.

1. Select **Settings** and press ✓
2. Select **Recovery Options** and press ✓
3. Select **Delete Downloaded Maps** and press ✓
4. Select **Delete** and press ✓ to delete all maps.