

inReach Support Center

Portal > Knowledgebase > inReach Devices > inReach SE+ > How-To > Deleting History Details using inReach SE+ / Explorer+


Deleting History Details using inReach SE+ / Explorer+

Administrator - 2017-03-09 - 0 Comments - in How-To


You can view your history details, the number of messages, preset messages, track points and other events sent from your device each day. Your history details will show you the amount of points sent by date.

This article explains how delete history details.

Deleting a specific history entry




1. Select **History** and press ✓
2. Select a day from the list and press ✓
3. Select an event record from the list and press ✓
4. The event record details will be displayed.
5. Press  and the **Details Menu** will be displayed.
6. Select **Delete** and press ✓
7. Select **Delete** and press ✓ to delete the selected history entry.

Deleting history for a specific day

1. Select **History** and press ✓
2. Select a day from the list and press ✓
3. All event record details for the day will be displayed.
4. Press  and the **History Menu** will be displayed.
5. Select **Delete Day** and press ✓
6. Select **Delete** and press ✓ to delete history for the selected day.

Deleting all history details

1. Select **History** and press ✓

2. All history will be displayed.
3. Press  and the **History Menu** will be displayed.
4. Select **Delete All History** and press .
5. Select **Delete** and press  to delete all history.