

inReach Support Center

Portal > Knowledgebase > inReach Devices > inReach SE+ > How-To > Editing a Waypoint using inReach SE+ / Explorer+

Editing a Waypoint using inReach SE+ / Explorer+

Administrator - 2018-10-25 - 0 Comments - in How-To

Waypoints are locations you create and store on the device. Waypoints can mark where you are, where you are going, or where you have been. When a waypoint is created or edited it will also appear on your MapShare page. Waypoints can be created using your inreach.garmin.com account or directly on your device.

This article explains how to edit to a waypoint.

1. Select **Waypoints** and press ✓
2. Choose a waypoint from the list and press ✓
3. Your waypoint location details will be displayed.
4. Select an option:
 - Edit the waypoint name by selecting the name and press ✓
 - Edit the location coordinates by selecting the location details and press ✓

TIP: If you wish to change the location of the waypoint you will need to delete and re-create the waypoint.