

inReach Support Center

Portal > Knowledgebase > inReach Devices > inReach SE+ > How-To > Performing a Factory Reset on inReach SE+ / Explorer+

Performing a Factory Reset on inReach SE+ / Explorer+

Administrator - 2017-03-10 - 0 Comments - in How-To

You can restore all device settings to the factory default values.

This article explains how to perform a factory reset.

1. Select **Settings** and press ✓
2. Select **Recovery Options** and press ✓
3. Select **Restore Factory Settings** and press ✓
4. Select **Reset** and press ✓ to reset the device.