

inReach Support Center





[Portal](#) > [Knowledgebase](#) > [inReach Devices](#) > [inReach SE+](#) > [How-To](#) > [Reversing a Route using inReach SE+ / Explorer+](#)

Reversing a Route using inReach SE+ / Explorer+

Administrator - 2018-10-25 - [0 Comments](#) - in [How-To](#)

A route is a sequence of points or locations that leads you to your final destination. You can create and save routes at inreach.garmin.com. After a route has been created you will need to sync your inReach device.

This article explains how to navigate a route in reverse.

1. Select **Routes** and press 
2. Choose a route from the list and press 
3. Press , select **Reverse Route** and press  to begin navigating.