

inReach Support Center

Portal > Knowledgebase > inReach Devices > inReach (Original) > How-To > Sending a preset message from inReach (Original)

Sending a preset message from inReach (Original)

Administrator - 2017-06-18 - 0 Comments - in How-To

The inReach (Original) device can send three unique preset messages by using the message button. Before using these messages, you must first create them by logging into the Explore portal at <https://inreach.garmin.com>, navigating to the "Messages" tab, and configuring the "Preset Messages."

To send a preset message hold down the message button

- One blink is message one
- Two blinks is message two
- Three blinks is message three

Release the message button when you would like to send the desired message.

The message button can be found on the diagram below.

