

inReach Support Center

Portal > Knowledgebase > inReach Devices > inReach SE+ > How-To > Sending a Preset Message using inReach SE+ / Explorer+

Sending a Preset Message using inReach SE+ / Explorer+

Administrator - 2018-10-25 - 0 Comments - in How-To

Preset messages are messages that are created your inReach account at inreach.garmin.com. Preset messages have predefined text and recipients. When a Preset message is selected the message will be automatically sent to the predefined recipient and include the predefined text.

This article explains how to send a Preset message.

1. Select **Preset** and press ✓
2. Select the desired preset message, and press ✓ to send.