

inReach Support Center

Portal > Knowledgebase > inReach Devices > inReach SE+ > How-To > Setting the Tracking Send Interval using inReach SE+ / Explorer+

Setting the Tracking Send Interval using inReach SE+ / Explorer+

Administrator - 2017-03-08 - 0 Comments - in How-To

Tracking records your path. When you start tracking, your device logs your location and updates the track line on the map at the specified log interval. Your device records track points and transmits them over the satellite network at the specified send interval. You can view the number of track points sent, storage space remaining, and time until the tracking log storage is full.

You can adjust the tracking log interval and the tracking send interval to capture the level of detail required or to maximize battery life.

This article explains how set the tracking send interval.

1. Select **Settings** and press ✓
2. Select **Tracking** and press ✓
3. Select **Send Interval** and press ✓
4. Choose a **Moving Interval** from the list and and press ✓

TIP: The more frequent the interval, a higher level of tracking detail will be captured. The less frequent the interval, the longer your battery will last.