

inReach Support Center

[Portal](#) > [Knowledgebase](#) > [inReach Devices](#) > [inReach SE+](#) > [Using the Settings Menu on inReach SE+ / Explorer+](#)

Using the Settings Menu on inReach SE+ / Explorer+

Administrator - 2017-03-10 - [0 Comments](#) - in [inReach SE+](#)

The Settings Menu on your inReach enables you to customize the behavior and various aspects of your device.

Use the articles below to assist with the different settings of your inReach device:

→ [Display Settings](#)

→ [Map Settings](#)

→ [Tracking Settings](#)

→ [Bluetooth Settings](#)

→ [Compass & Altimeter Settings](#) (Explorer+ Only)

→ [Message Settings](#)

→ [Sound Settings](#)

→ [Time Settings](#)

→ [Units Settings](#)

→ [External Power Settings](#)

→ [Language Settings](#)

→ [Owner Info Settings](#)

→ [Device Information](#)