

# inReach Support Center

[Portal](#) > [Knowledgebase](#) > [inReach Devices](#) > [inReach SE+](#) > [How-To](#) > [Viewing Message Details using inReach SE+ / Explorer+](#)

## Viewing Message Details using inReach SE+ / Explorer+


Administrator - 2017-03-09 - [0 Comments](#) - in [How-To](#)

When a message is sent, the message contains details related to the message content, recipient, date, location, speed, course, and elevation.

This article explains how to view the message details associated to an inReach+ message.

1. Select **Messages** and press 
2. Select the desired conversation in the list and press 
3. Select a message that includes  and press 
4. The message details will be displayed.
5. Select an option:

Select **Navigate** to navigate to the location from which the message was sent.

Select  followed by **View on Map** to view the location on the map and from which the message was sent.