

# inReach Support Center

Portal > Knowledgebase > inReach Devices > inReach Explorer > How-To > Deleting Track Logs from the inReach Explorer

---

## Deleting Track Logs from the inReach Explorer

Administrator - 2015-07-21 - 0 Comments - in How-To

Perform the following steps to delete the track log from your inReach Explorer device.

### Step 1: Sync device

You will need to sync your device via the inReach sync client. This will copy the track logs to the explore.delorme.com portal.

Sync for


Windows: <http://support.inreachcanada.com/kb/articles/14-inreach-se-inreach-explorer-sync-for-windows>

Sync for Mac: <http://support.inreachcanada.com/kb/articles/15-inreach-se-inreach-explorer-sync-for-mac>


### Step 2: Delete track log

Once the sync has been completed, and the logs have been uploaded to explore.delorme.com, you can delete the track log by doing the following:


1. From the inReach Explorer main menu select the "Tracking" option.
2. Select "Clear."



3. The device will ask if you are sure, select "Clear."



4. You will have the option to select "Reset All" or "Reset Trip."



5. The logged data will be removed from the device memory. The logging info will remain on [explore.delorme.com](http://explore.delorme.com).