

# inReach Support Center

Portal > Knowledgebase > inReach Devices > inReach SE+ > How-To > Checking for Messages using inReach SE+ / Explorer+

---

## Checking for Messages using inReach SE+ / Explorer+

Administrator - 2017-03-07 - 0 Comments - in How-To

This article explains how to check for messages.

Your inReach+ listens for new messages at regular listen intervals. Satellites announce recently sent messages, and your device receives the message at the next listen interval. The default interval is 10 minutes.

**NOTE:** Your device must be in view of a satellite at the time of the listen to receive messages.

You can force a check for messages by manually checking for messages, sending a message, or sending a track point. During a check, your device connects to satellites and receives undelivered messages waiting to be sent to your device.

**TIP:** You can adjust the listen interval to check more frequently or to maximize battery life under **Settings** > **Messages**

To check for undelivered messages:

1. Select **Check** and press ✓
2. Select **Check Now** and press ✓