

inReach Support Center

Portal > Knowledgebase > Earthmate App > iOS (iPhone, iPad, iPod) > How-To > Pairing inReach SE+ / Explorer+ with iPhone, iPad, or iPod

Pairing inReach SE+ / Explorer+ with iPhone, iPad, or iPod

Administrator - 2017-03-08 - 0 Comments - in How-To

You must pair your inReach+ device with your mobile device to use the Earthmate app.

This article explains how to pair your inReach+ with an iPhone, iPad or iPod.

1. Using your iOS mobile device, navigate to **Settings**.
2. Select **Bluetooth** and turn Bluetooth on. Your iOS mobile device will begin scanning.
3. Place the inReach device and your mobile device within 3 m (10 ft.) of each other.
4. On the inReach device, select **Settings > Bluetooth > Pair Device > Pair Device**.
5. On your iOS mobile device, select the **inReach XXXXXXXX** entry once it appears.
6. Once connected, the inReach will display **Pairing Successful** at the top of the screen and **App Not Installed** will be displayed on your iOS mobile device, select **App Store** to download the Earthmate app.
7. Install and open **Earthmate** to begin using the Bluetooth features.

After the devices are paired, they will connect automatically when they are powered on and within range.